

# Assembly and Installation Guide

# 2021 Series OXXO Supplement





# **OPERATING PANEL INSTALLATION**

# **PROCEDURE:**

# **Placing the Operating Panels**

- Lift the operating panel into the interior track of the header as shown.
- Swing the operating panel towards the sill.
- Carefully lower the panel onto the roller track.

#### **Adjusting Operating Panel Height**

**NOTE:** The operating panels may need to be adjusted for squareness and airtightness. It is recommended to lower the rollers to the lowest possible position while maintaining squareness with the frame. If the panel is dragging on the track, raise the rollers accordingly.

**NOTE**: The operating panels must be adjusted prior to affixing the hardware, specifically the keeper.

- Slide the panel in the closing direction to within ¼" of the jamb.
- Ensure that the gap between the panel and the jamb is uniform from top to bottom.
- Adjust the panel with a screwdriver as shown, (upwards or downwards) as necessary, until the panel aligns to the jamb.

**NOTE:** Take the weight off the wheels (lift the panel slightly) during adjustment for ease of turning and to ensure against stripping the adjustment mechanism.

**NOTE:** If the jamb is NOT straight, remove the installation screws, adjust the shims, and refasten.



# SUPPLEMENTAL INSTRUCTIONS: OXYO/OYXO 4 PANEL

# **PROCEDURE:**

The H-bar is installed on the 'dummy' operating panel. Place the H-bar against the vertical rail of the 'dummy' moving panel.

One side of the H-bar will be lined with 1/16" thick black foam which will go against the dummy moving panel.

Align thermal break of the H-bar to line up with thermal break of dummy panel rail.

**NOTE:** The H-Bar adapter will be affixed to the panel with a **RED**-headed screw. This is only for transport purposes. Remove the red screw and the H-Bar from the panel with appropriate, supplied fasteners.

Once the panels are installed and levelled, the H-Bar can be installed. See instructions below.



# POCKET COVER & SILL THRESHOLD COVER INSTALLATION

**NOTE:** The pocket covers are designed to be installed in one orientation only. Ensure the longer leg is in the correct position, as shown in the diagrams below.

# **PROCEDURE:**

# Vertical Pocket Covers for jambs are on interior

#### Installing the Jamb Pocket Covers

- Fit the jamb pocket cover into the unoccupied slot as shown.
- > Ensure the longer leg is towards the interior.
- Use a mallet if needed, to snap the pocket cover tightly into place.
- Repeat the previous steps for the other jamb.

# Header Cover and Threshold and installed on exterior side

#### Installing the Header Cover

- Fit the header pocket cover in the exterior header slot as shown.
- > Ensure the longer leg is towards the interior.
- Use a mallet if needed, to snap the pocket cover tightly into place.

**NOTE:** The exterior header pocket cover can only be installed in the orientation shown. Ensure the longer leg is in the correct position.

# Installing the Sill Threshold Cover

- Place the sill threshold cover between the fixed panels as shown.
- Ensure the sill threshold cover slopes towards the exterior.
- Use a mallet to snap the threshold cover securely in place.

**NOTE:** The sill threshold cover should fit snugly. If it does not, the fixed panel is NOT fitted all the way into the jamb. Reinstall the fixed panel and try again.

